
GARAGE LASER PARK

Instructions


Included Parts:

- 1 Garage Laser Park (main unit) with Mounting Bracket
- 1 AC Adapter (120V AC input, 9V DC output)
- 3 Screws
- 2 Double-Stick Tape
- 1. Detach black mounting bracket from the main unit. Find a suitable place and attach the mounting bracket to the ceiling or wall as shown with the 3 screws or double-stick tape.

CAUTION: Do NOT use double-stick tape to mount the unit on a ceiling. Mount securely with screws.




2. Slide the main unit into the black mounting bracket as shown.



3. Mount the unit close to an electrical outlet (typically near the one used to power your garage door opener). Plug in the AC adapter. The battery is only a backup if power is interrupted and will not last for more than a few days. To install the backup battery, remove the screw on the rectangular battery compartment on top of the main unit.

4. Park your car in the desired position.
Adjust the laser beam so that it shines on a prominent feature on the car. Good choices include a spot on your dashboard or the space between the hood and the windshield. Remember, you must be able to see the spot from the driver's seat while parking the car.



5. When your car first enters the garage, the motion detector will turn on the laser. Drive forward until the laser beam hits your pre-determined spot indicating that you are parked in the correct position. The laser will turn off automatically after you are parked.



This product complies with 21 CFR chapter 1, section 1040-10

AVOID EXPOSURE, LASER
RADIATION IS EMITTED FROM

- Laser devices can be harmful if used improperly.
- Do not aim into eyes.
- Do not look into aperture while laser is on.

1 YEAR
Limited Warranty

Indoor Use Only
Made in China

MAXSA

MAXSA Innovations, LLC 8412 Cathedral Forest Drive Fairfax Station, VA 22039

ONE YEAR LIMITED WARRANTY

MAXSA Innovations, LLC warrants to the original consumer/purchaser that this product shall be free of defects in material and workmanship under normal use and circumstances for a period of **one** (1) year from the date of original purchase for use. When the original consumer/purchaser returns the product pre-paid to MAXSA Innovations, LLC, 8412 Cathedral Forest Dr; Fairfax Station, VA 22039; USA within the warranty period, and if the product is defective, MAXSA Innovations, LLC will at its option repair or replace such.

This warranty shall constitute the sole liability of MAXSA Innovations, LLC concerning the product. MAXSA Innovations, LLC expressly disclaims all other warranties INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO PERSON, FIRM, OR CORPORATION IS AUTHORIZED TO ASSUME FOR MAXSA INNOVATIONS, LLC ANY OTHER LIABILITY IN CONNECTION WITH THE SALE AND USE OF THE PRODUCT. MAXSA Innovations, LLC and agents and distributors will bear no liability whatsoever for incidental or consequential damages or charges of any kind.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above disclaimer regarding incidental or consequential damages may not apply to you.

This warranty is void if the product has been damaged or tampered with or if the product or any such parts have been opened. In all cases of damage during shipment, a claim must be filed with the shipping carrier and not with MAXSA Innovations, LLC.

This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

OUT OF WARRANTY REPAIRS

If the warranty period has expired, MAXSA Innovations, LLC will at its option either (1) replace this product with a functionally similar (but not necessarily identical) refurbished product or (2) repair the original product and return it to the original consumer/purchaser after payment of repair/replacement charges has been received.